

POWERFLEX®

PART NUMBER

PFF1-813

DESCRIPTION

ENGINE MOUNT STABILISER BUSH (V6 ONLY)

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane A Bushes
- 1 x PTFE/Silicone Grease
- 2 x Stainless Steel Sleeves
- 2 x Zinc Plated Mild Steel Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the original rubber bushes from the mount and clean any rust or corrosion from the mount. File off any sharp edges.
2. Fit the polyurethane bush into the mount, and apply some of the supplied grease to the bore of the bush.
3. Push the stainless steel sleeve into the bore of the bush until it sits flush.
4. When fitting the mount back to the car, place a washer on each open end where the bush meets the engine.
5. Tension all hardware to manufacturers recommended torque settings.

