

# POWERFLEX®

## PART NUMBER

# PFF1-601

## DESCRIPTION

# FRONT LOWER ARM FRONT BUSH

## INSTALLATION GUIDE

### Contents (parts per pack):

- 4 x Polyurethane Bushes
- 1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



### Fitting Instructions:

1. Remove the original rubber bush from the front lower arm without damaging the original sleeve. This is best done by burning the rubber bush off the original sleeve.
2. Carefully clean any dirt and corrosion from the bore of the arm and the original sleeve, and file off any sharp edges.
3. Apply some of the supplied grease to the bore of the bushes and the centre of the sleeve.
4. The sleeve is fitted into the dips of two polyurethane parts, as shown in figure 1.
5. Push the polyurethane parts and sleeve assembly into the bore of the arm. **TIP: Apply some washing up liquid to one end of the bush to aid fitting.**
6. Tension all hardware to manufacturers recommended torque settings.

